



Section Variables

Creer ou impoter des sections de base selon le besoin



Creation des sections variables

Add Frame Section Property

Select Property Type
Frame Section Property Type Other

Click to Add a Section

General Nonprismatic Section Designer

The 'Nonprismatic' section type is highlighted with a red box and a red arrow points to the 'Other' dropdown menu.

Nonprismatic Section Definition

Nonprismatic Section Name PG Display Color Red

Section Notes Modify/Show Notes...

Start Section	End Section	Length	Length Type	EI33 Variation	EI22 Variation
30x70	30x50	1,	Variable	Linear	Linear
30x70	30x50	1,	Variable	Linear	Linear

Add Insert Modify Delete

Nonprismatic Section Definition

OK Cancel


Nonprismatic Section Name PD Display Color Yellow

Section Notes Modify/Show Notes...

Start Section	End Section	Length	Length Type	EI33 Variation	EI22 Variation
30x50	30x70	1,	Variable	Linear	Linear
30x50	30x70	1,	Variable	Linear	Linear

Add Insert Modify Delete


OK Cancel




Assigner les sections variables:

1-Selection des éléments

2-Assign → Frame → Frame section






Pour décaler les éléments on procède comme suit:

1-Selection par élément.

2-Assign → Frame → insertion point



Assign Frame Insertion Point

Cardinal Point

Cardinal Point **10 (Centroid)**

Mirror about Local 2 Axis
 Mirror about Local 3 Axis

Frame Joint Offsets to Cardinal Point

Coordinate System **GLOBAL**

	End-I	End-J
Global X	0 m	0,1 m
Global Y	0 m	0 m
Global Z	0 m	0 m

Stiffness Transformation

Do Not Transform Frame Stiffness for Offsets from Centroid

Reset Form to Default Values

OK **Close** **Apply**

Cardinal Point

Cardinal Point **10 (Centroid)**

Mirror about Local 2 Axis
 Mirror about Local 3 Axis

Frame Joint Offsets to Cardinal Point

Coordinate System **GLOBAL**


	End-I	End-J
Global X	0 m	0 m
Global Y	0 m	0 m
Global Z	-0,1 m	0 m

Stiffness Transformation

Do Not Transform Frame Stiffness for Offsets from Centroid

Reset Form to Default Values

OK **Close** **Apply**



Assign Frame Insertion Point

Cardinal Point

Cardinal Point **10 (Centroid)**

Mirror about Local 2 Axis
 Mirror about Local 3 Axis

Frame Joint Offsets to Cardinal Point

Coordinate System **GLOBAL**

	End-I	End-J
Global X	0 m	-0,1 m
Global Y	0 m	0 m
Global Z	0 m	0 m

Stiffness Transformation

Do Not Transform Frame Stiffness for Offsets from Centroid

Reset Form to Default Values

OK **Close** **Apply**

Assign Frame Insertion Point

Cardinal Point

Cardinal Point **10 (Centroid)**

Mirror about Local 2 Axis
 Mirror about Local 3 Axis

Frame Joint Offsets to Cardinal Point

Coordinate System **GLOBAL**

	End-I	End-J
Global X	0 m	0 m
Global Y	0 m	0 m
Global Z	0 m	-0,1 m

Stiffness Transformation

Do Not Transform Frame Stiffness for Offsets from Centroid

Reset Form to Default Values

OK **Close** **Apply**